


8. Perform the 'INSPECTION AFTER TRANSMISSION INSTALLATION', and verify that there is no malfunction.



N·m (kgf·m, ft·lbf)

1	Shift lever knob
2	Upper panel